

MBS High Strength Spray Contact Adhesive

Technical Datasheet

The MBS High Strength will bond a wide variety of substrates, including wood, metals, rubber, fabric, and most plastics, cardboard, polythene, and concrete, as well as decorative laminates. It is ideal for permanent bonds that require good initial bond strength. It provides good temperature resistance and if protected from contamination has an open time of several hours. Always test a small sample of the materials first to ensure the suitability of the product for the application. For instance, some vinyls contain large amounts of plasticiser which, over time, can migrate and soften the bond. **Do not use on flexible PVC or expanded polystyrene.**

Features

- ❖ HIGH-TEMPERATURE RESISTANCE
- ❖ LONG OPEN TIME
- ❖ FAST & EASY APPLICATION
- ❖ UNIFORM SPRAYING
- ❖ LOW ODOUR
- ❖ HIGH SOLIDS

Technical Specifications

Solvent:	Dichloromethane
Propellant:	Hydrocarbon
Solids:	Content (approx.) 25-30%
Spray Pattern:	Web
Colour:	Clear
Coverage (17kg canister):	~ 128m ²
VOC:	718g/l
Shear Adhesion Failure Temp:	>100°C
Available Sizes:	17kg, 85kg, 130kg

Storage

Do not stand on a cold concrete floor or allow the product to freeze. Protect from extremes of temperature in a controlled environment between 15 and 35°C, and away from direct sunlight. Low temperatures can result in irreparable separation of the adhesive. If the adhesive sprays like a jet, the canister is too cold. Warm to at least 10°C before using. Stored under the correct conditions, in original, unopened containers, the product will have a shelf life of 12 months.

MBS High Strength Spray Contact Adhesive

Technical Datasheet

Directions

1. Surfaces should be clean, dry, and free from grease, oil, and dust. Excessive dust will impair performance. For best results, the substrate and product should be bonded at temperatures between 5°C to 25°C.
2. Attach a suitable spray nozzle, such as a Unijet 6501, to the spray gun.
3. Connect the hose to the canister and the spray gun to the hose and tighten the connections. If there are any leaks, tighten the connection at the source of the leak.
4. Open the valve on the canister. The valve should remain open until the canister is used up. Use the locking nut on the gun after use. Turning off the valve will result in the adhesive drying in the hose and gun causing blockages.
5. Hold the spray gun 10-20cm away at 90° to the surface and apply a uniform coat of adhesive, to both substrates, ensuring 80-100% coverage. Spray one surface vertically and the other horizontally. Pay particular attention to the edges.
6. When the adhesive is dry to the touch it is ready for the bond to be made.
7. Porous substrates may require two applications.
8. Drying takes approximately 1 to 2 minutes depending on substrates, ambient temperature, and humidity. Over-spraying and pooling of the adhesive will increase the drying time and may cause the adhesive to show through the laminate.
9. After spraying, remove the spray gun tip and rinse with Solvent Cleaner before it has cured.
10. It is important to remember that the MBS High Strength is a contact adhesive and forms a bond by sticking to itself, so there must be sufficient adhesive on both surfaces for this to happen.
11. Allow the adhesive to tack up and protect from contamination whilst this happens. The adhesive is ready to bond when it feels dry to the touch and does not transfer.
12. Once the two surfaces have been brought together, an aggressive bond will be made. Spacers can be used to ensure the surfaces do not come into contact prematurely.
13. Once the two surfaces are brought together, apply a uniform pressure over the workpiece, starting in the middle and working outwards. Use blocks or a 3-inch roller and ensure the whole piece has been worked to ensure adequate contact with the adhesive.
14. Pay particular attention to the edges. Please note that testing at this point by lifting the edge will weaken the bond. A nip roller will give the best results.
15. Once assembled, the piece can be machined or trimmed as required. Full cure will take 24 hours.
16. Keep the valve open and the hose attached to the canister until there is no more adhesive. If the hose is removed, clean through with solvent cleaner to prevent adhesive drying, which will cause the gun and hose to block. Turn the canister off before removing the hose.



MBS High Strength Spray Contact Adhesive

Technical Datasheet

Disclaimer

All the information in the Data Sheet is based on practical experience and is published in good faith. However, because we have no control over the manner or conditions in which our products are used, or over work undertaken or product manufactured by the purchaser, we cannot accept liability for results. Responsibility for ascertaining the suitability of products for his purposes rests with the purchaser. All conditions, representations, statements, warranties, or guarantees whatsoever, whether express, implied, or statutory, in respect of any goods manufactured, sold, or supplied by us are hereby expressly excluded and we accept no liability in respect of any claim for damage or consequential loss caused to any property arising directly or indirectly out of the use of our products or goods.